

12. Install inside corner trim at each corner once you have the adjacent wall covered with our panel. You may want to put a small bead of clear silicone caulk on the backside of the inside corner before you install it to make a tight corner.
13. Proceed with installing the remaining wall panels, bottom J-trim and inside corner trim.
14. Install J-trim or outside corner at door and window openings prior to installing the wall panels. This makes a nice clean border around your windows and doors.

NOTE: Recommended Screws (Fasteners)

3/4" Stainless Steel Wafer Head Screw (wood)

3/16" x 1 1/4" Tapcon screw

NOTE: It is recommended that the wide truss head screw should go into the wood and the tapcon screw should go into the masonry block. It takes a little longer to to install, but the panel will stay in place.

Horizontal Wall Panels

- 1.) After trim is installed start hanging the wall panels from the top down to the floor. So, start at the ceiling with the first panel and install with nailing din pointing to the floor, groove down. This way, no water will lay in the groove.
- 2.) Proceed to install the remaining panels as directed above.
- 3.) You may need to cut the last panel, near the floor. Measure and cut 1/2" short, rip on table saw, with fine tooth blade. Install panel by dropping down into J-trim then raising up into previous panel.

Cutting Panels

Flat and Beaded panels can be cut by using these method:

- A. Table saw with fine tooth plywood blade or 160-tooth carbide blade.
- B. Cut through product slowly, don't rush
- C. Wear safety glasses.
- D. Powered miter saw with fine tooth blade.
- E. Fixed blade utility knife and a straight edge to guide knife. Score area 4-6 times with sharp knife to cut through product.
- G. Temperature is a factor when working with vinyl. Warm weather is no problem but cold temperatures can create some issues.

IN COLD CLIMATES

- A. Bring panels inside and warm to 50 degrees or warmer, if possible, overnight.
- B. Do not install too tight when cold. When it warms up your panels will grow. Allow a little play; place a nickel between the panels if it is below 25 degrees F.

TOOLS REQUIRED:

1. Hammer
2. Utility Knife
3. Level
4. Wide blade putty knife
5. Drill
6. Caulk gun
7. Masonry drill with 5/32" masonry bit
8. Silicone caulk
9. Wood block to set panels

*North Brook is NOT responsible for expansion problems. The warranty on this product is null and void if not installed according to our instructions.

Please call us toll free at 1-877-624-2638 if you have any questions.

North Brook Farms, Inc.

www.northbrookfarms.com