

PRODUCTS BY NORTH BROOK FARMS INC.

SUPERSTALL

Installation Instructions

Ground Preparation: Concrete is best, however, if the stall area is earthen or stone it should be level and well packed before installing the foam mat.

Foam Installation: Lay mattress according to schematic provided. There is no up or down side. Butt each edge of the mattress to one another and to the edge of the stall walls leaving no gaps.

- If you have posts or doorways, carefully compress to fit around the doorway or post.

Top Cover Installation: Your cover will be pre-cut according to measurements provided in your order.

- Be sure to reference your cut length according to the North Brook Farms schematic provided. The black basket weave side is the top, the woven side is the bottom of the cover.
- Spread the cover over the stall.
- Crease the cover where the foam meets the wall to form a 90-degree edge. Make sure the cover is lying that without wrinkles or bubbles.
- Kick the fabric in place, out to the edges of the stall, so it is even and flat in the stall or use a 2x4 to ensure the cover is tight to the edge of the stall.
- Fasten the width direction first. Vertically notch the fabric at the corner where the foam and fabric meet, to form two “wings” (that will be tucked behind and over the plastic strip). Be sure to have a **sharp** knife and extra blades.
- Be very careful when cutting the fabric not to injure the foam or cut the fabric too deeply, leaving the foam exposed in the corner. Measure the wall corner to corner. Cut the other corner of the same wall.
- Cut enough plastic strips to cover the length. The plastic strips are 8 ft. long. You may need to use a part of another strip to complete the attachment
- To cut the strip, score the plastic several times, then snap the strip with your hands. Be sure to save the remaining strip to use on the other walls.
- Begin fastening the plastic strip against the top cover. Use a 1 5/8” deck star drive (if stall walls are wooden) or a 1 5/8” tap-con screw (if stall walls are concrete) to fasten fabric and plastic strip to the walls. The plastic strip does not need to be predrilled.
- The plastic strip should be resting on top of the foam or slightly recessed if possible.
- Start at one end and continue to the other end. Do not start in the middle. Proceed to the opposite wall and repeat the cutting, measuring, and fastening steps.
- Fasten the walls across from each other (side, side, back , front). The cover should not have any wrinkles, or bubbles, but should not be pulled too taut. It should be smooth and rest on top (be touching) of the foam. If you have post or doorways, the fabric will need to be cut.

Call the office for assistance or with any questions. GOOD LUCK!

North Brook Farms

Toll Free 1-877-624-2638

Email: North.Brook.Farms@gmail.com

www.NorthBrookFarms.com